

```
function theta=angp(SIGxx,SIGyy,SIGxy)
% function angp.  Calculates a principal stress orientation
theta = 0.5*atan2(SIGxy,(SIGxx-SIGyy)/2);
```