

```
function S1=SIG1(SIGxx,SIGyy,SIGxy)
% function SIG1.  Calculates one 2-D principal stress magnitude
S1 = (SIGxx+SIGyy)/2 + sqrt( ((SIGxx-SIGyy)/2).^2 + SIGxy.^2);
```